



OPA 285RKTB

Packaged Reverse Cycle R410A Air Cooled Air Conditioner

GENERAL

This OPA 285RKTB unit must be installed in accordance with all national and local safety codes.

CONFIGURATIONS

The OPA 285RKTB is supplied in one of two standard configurations :

1. Horizontal supply/return air with box mounting channel (RKTBH), or
2. Downward supply air with box mounting channel (RKTBU).

REFRIGERATION SYSTEM

General

The OPA 285 has two independent refrigeration circuits and two compressors to provide the flexibility and economy of two stage operation, i.e. utilising one or two circuits as conditions vary, plus the advantage of staggered starting.

Tapping points are provided to measure discharge and suction operating pressures.

Compressors

The compressor is directional scroll type. The compressor lubricant is polyol ester oil (POE). Note, this oil absorbs moisture quickly if exposed to open air. On commissioning, the compressor must be checked for correct rotation (refer Start Up Procedure).

ECONOMISER (Option)

If the outdoor air heat content or temperature is below that of the return air, the fresh air damper opens and the return air damper closes to provide the first stage of cooling. The compressor(s) will then operate to provide more cooling if required.

INSTALLATION

Unpacking

Units configured with Downward supply air and mounting rails, have their spigots shipped loose inside the return air cavity.

Positioning

Refer to dimension diagrams for minimum clearances. If multiple units are to be placed side-by-side then allow at least 2 m between coil faces.

Mounting

The unit should be fastened to a firm flat horizontal base using the holes supplied in the box mounting channel.

When the unit is being installed on a roof it is recommended that the unit is installed on a substantial structure with vibration

isolating springs beneath the unit. These springs are not supplied with the unit.

Flexible duct connections are recommended between the supply and return ducts and the unit.

Condensate Drain

The condensate drain should be 'U' trapped outside the unit. The trap should have a Downward height of at least 100 mm. The drain should have a slope of at least 1 in 50 and must not be piped to a level above the unit drain pipe (see figure 3).

Electrical Requirements

Electrical work must be done by a qualified electrician. The outdoor unit must be wired directly from a distribution board by means of a circuit breaker or H.R.C. fuse, and a mains isolator provided - preferably close to the unit.

Note: DO NOT USE REWIRABLE FUSES.

The OPA 285 is provided with a 24V AC control circuit for a thermostat, on/off switch and/or time clock.

The control transformer 240V primary voltage is used for countries with 230-240V power supply. For countries with supply voltages 200-220V, change the primary voltage on the transformer to 208V.

Standard units are suitable for use with thermostats with either manual Heat/Cool selection or automatic changeover subject to the contact ratings of the thermostats.

A 24 hour power supply to the compressor crank case heaters is required, otherwise the warranty is void.

CHECK TESTS

1. Leave the on/off switch in the off position and close the mains isolating switch. A four hour delay period is required to allow the crankcase heaters to drive any liquid refrigerant out of the compressor oil. Bypass the crankcase heater thermostat (CCHT) for this period only.
2. Check that the shipping block beneath the compressor has been removed and that the compressor is secure on its mounts.
3. Check that all fan motors are free running.
4. Check that the thermostat is correctly wired to the unit and is set at the desired temperature.
5. Check that the air filters have been correctly installed if fitted.
6. Check air diffuser dampers are open if appropriate.

Installation & Maintenance

START UP PROCEDURE

Use the supplied Commissioning Sheet to help you complete the following procedure:

1. After the four hour delay period has expired, switch on the unit. Ensure the crankcase heater thermostat has been reconnected.
2. The compressor fitted is directional. Check for correct rotation. If rotation is incorrect the compressor will not pump, be noisy, and will draw minimal current. To correct motor rotation, change the phasing at the main power terminal. If changing the phasing, check the indoor air fan then runs in the correct direction also.
3. Check the supply voltage between each phase and neutral.
4. Measure the current draw on each phase to the compressor motor and measure the current draw of each fan motor. Check all readings against the specified values in the wiring diagram.
5. Fit gauges and measure the suction and discharge pressures of both refrigeration circuits.
6. Check that the outdoor air fan motors are running smoothly.
7. Test the operation of the reversing valve by running the unit in both the heating and cooling mode.
8. Check the indoor unit's fan belt tension after 20 mins of operation and adjust if necessary (refer Commissioning Sheet).
9. Check the supply air flow at each outlet.
10. Check the tightness of all electrical connections and sign the check label.
11. Touch up any outdoor unit paintwork damage to prevent corrosion.

SETTING SUPPLY AIR FLOW

Consult OPA 285 Technical Data pamphlet for details of airflow/duct static pressure, if required.

If the indoor air returning to the unit is regularly expected to be above 50%RH, then the coil face velocity should be limited to be 2.5 m/s or less (refer Air Handling graph in Technical Data pamphlet).

High humidity levels can occur in tropical or subtropical conditions, and/or when heavily moisture laden fresh air is introduced. Select a fan speed that avoids water carry-over problems.

In a free blow or low resistance application, beware of exceeding the fan motor's full load amp limit (refer wiring diagram).

The indoor air fan motor is fitted with a factory set adjustable pitch pulley. Instructions for the adjustment of pulleys is included on the back page of the supplied

Commissioning Sheet. One revolution of adjustment is equal to approx. 7% change in air volume flow rate.

OUTDOOR UNIT CONTROLLER (OUC)

The Outdoor Unit Controller (OUC) includes a temperature sensing head pressure control which enables the system to compensate for outdoor ambient temperatures below 20°C on cooling cycle, and above 15°C on heating cycle. The OUC also has features which protect against icing or overheating of coils, rapid cycling of the compressor and loss of refrigerant charge.

If the outdoor unit fans take some time to begin rotating when the system is powered on, or they don't appear to be rotating appropriately while the compressor is running, consult the OUC label on the electrical box. If necessary, refer to **temperzone** for further diagnostic information.

MAINTENANCE

Monthly

1. Check air filters, if fitted, and vacuum or wash clean as necessary.
2. Check condensate drain for free drainage.
3. Check compressor compartment for oil stains indicating refrigerant leaks.

Three Monthly (or every 1200 hrs of operation)

Check the indoor unit's fan belt tension and adjust if necessary.

Six Monthly

1. Check the tightness of electrical connections.
2. Check the tightness of fans, motor mountings, pulleys and belt tension.
3. Check suction and discharge operating pressures.
4. Replace indoor air filters (if fitted).
5. Check condensate drain for free drainage.

Yearly

1. Check all refrigerant piping for chafing and vibration.
2. Check the operation of electric heaters, if fitted.
3. Check air supply at all diffusers.
4. Check for excessive noise and vibration and correct as necessary.
5. Check for insulation and duct damage and repair as necessary.
6. Remove lint and dust accumulation from outdoor coil fins.
7. Touch up any paintwork damage to prevent corrosion.


NOTE

The manufacturer reserves the right to make changes in specifications at any time without notice or obligation. Certified data is available on request.


This pamphlet replaces the previous issue no. 3080 dated 04/09.
Wiring revisions A & B.

DIMENSIONS (mm)

Fig. 1 OPA 285RKTBH – Horizontal Supply & Return Air



OPA 285RKTB




Not to Scale

POINT LOADS (kg)			
W	X	Y	Z
107	86	105	127

Net Weight 425 kg



Note : A 2 m clearance is required above the exhaust air fans



DIMENSIONS (mm)

OPA 285RKTB

Fig. 2 OPA 285RKTBU – Downward Supply & Return Air



Not to Scale

Note:
Supply and return air spigots
are shipped loose inside the
return air cavity.





Fig. 3 Condensate Drain



NOTE

The manufacturer reserves the right to make changes in specifications at any time without notice or obligation. Certified data is available on request.

CAPACITIES - NET to AS/NZS 3823

COOLING	kW 27.72
ELECTRICAL INPUT	kW 25.83
COOLING - REVERSE CYCLE	kW 8.850
E.E.R. (COOLING)	kW/kW 3.132

ELECTRICAL

SUPPLY REQUIRED 3Ph 342-436V ~ 50Hz
COMPRESSOR (3Ph) RUN AMPS RATED CONDITIONS A/Ph 6.4 x 2
INDOOR FAN MOTOR (3Ph) FULL LOAD AMPS kW 1.1
OUTDOOR FAN MOTOR (1Ph) FULL LOAD AMPS A 2.5
OUTDOOR MOTOR CAPACITOR NFD B x 2
RUNNING AMPS (TOTAL) A 1.7 x 2
RECOMMENDED EXTERNAL PROTECTION SIZE A/Ph 40
ELECTRIC HEAT OPTION 6 kW TOTAL, A/Ph 8.7
RECOMMENDED EXTERNAL PROTECTION WITH ELECTRIC HEAT OPTION A/Ph 50
WEIGHT - NETT OPA 285RKIT Kg 425
REFRIGERANT - R410A Kg / SYSTEM 4.2

OIL TYPE : POLYESTER (P.O.E.)

APS AIR PRESSURE SWITCH HR2 HEATING RELAY 2
CAP. CAPACITOR HRC HEATING RELAY COIL
CB CRANKCASE HEATER HR2C HEATING PRESSURE SWITCH
CCH CRANKCASE HEATER 7' T/STAT HST HIGH TEMP. SAFETY
CLT COMPRESSOR LOW LIMIT T/STAT IFCC INDOOR FAN CONTACTOR
CM COMPRESSOR MOTOR IFM INDOOR FAN MOTOR
OMCC COMPRESSOR CONTACTOR IFOL INDOOR FAN OVERLOAD
OMOL COMPRESSOR OVERLOAD LAT LOW AMBIENT T/STAT
OR COMPRESSOR RELAY 24V CONTROL LP LOW PRESSURE SWITCH
DMF DAMPER MOTOR FRESH AIR OFM OUTDOOR FAN MOTOR
DMR DAMPER MOTOR RETURN AIR OUC OUTDOOR UNIT CONTROLLER
DO TIME DELAY 30 SEC. DELAY ON WAKE PRC PHASE ROTATION CONTROL
DR DE-ICE RELAY PRR PHASE ROTATION RELAY
DRC DE-ICE RELAY COIL PRRC PHASE ROTATION RELAY COIL
EHC ELECTRIC HEAT CONTACTOR RCV REVERSE CYCLE VALVE
EHCC ELECTRIC HEAT CONTACTOR COIL Z DE-ICE INHIBIT LEAD
FRC INDOOR FAN CONTROL
FR INDOOR FAN CONTROL RELAY
HR INDOOR FAN CONTROL RELAY COIL
HR HEATING RELAY

IMPORTANT NOTE:
THESE COMPRESSORS ARE DIRECTIONAL.
ENSURE COMPRESSOR IS ROTATING IN CORRECT DIRECTION.
WRONG DIRECTION WILL CAUSE NOISY OPERATION AND WILL NOT PUMP. REVERSE TWO PHASES TO CHANGE DIRECTION.

**NOTE: WIRE FROM FR-2 TO GR-4 (1).
CHANGES TO FR-2 TO HR-2-4 WITH THE ECONOMISER OPTION**

NOTE:
24 HOUR POWER SUPPLY TO CRANK CASE HEATER

DAMPER TERMINALS
Y = 0-10 VOLT DC
GO = COMMON
G = 24VOLT HOT

NOTE: CHECK WIRING BEFORE CONNECTION. WILL DAMAGE MOTORS.

CLIENT WIRING
Interconnections between units by client. Double insulated multi-core cable.

R410A

OPA 285RKTB

WIRING SCHEMATIC

Temperzon

NOTES:
1. The system "1" is sometimes referred to as "HST" system.
2. The system "2" is sometimes referred to as "IFCC" system.
3. Transformer 240V primary voltage is used for countries with 230-240V power supply for countries with supply voltage 200-220V change primary contact to secondary contact.
4. Red to service valve pipe pocket.
Yellow to coil return bend pocket.
Blue to bottom of coil in fins.

Drawn SDH Date 21-01-09 Drawing No. 556-224-002 B
Scale **1:25**