

OSA 147R

Single Phase Reverse Cycle Split System Outdoor Unit

Installation & Maintenance

GENERAL

This OSA 147R Outdoor Unit must be installed in accordance with all national and local safety codes.

INSTALLATION

Positioning & Mounting

Remove the four rubber mounts (supplied loose) from inside the compressor compartment.

Refer to dimension diagram below for minimum clearances. Mount either free standing or on a wall using the optional mounting brackets available.

Free Standing :

Fasten the unit down to a firm flat horizontal base using the four holes provided in the mounting rails. To avoid transfer of vibration, mount the unit on the four rubber mounts supplied. The base platform must not touch the exterior or concrete footing of any nearby wall.

When the unit is being installed on a steel roof it is recommended that the unit is

installed on a substantial structure with vibration isolating springs beneath the unit. These springs are not supplied with the unit.

Wall Mounting Option:

Complete wall mounting instructions are supplied with the optional wall mounting kit. To avoid transfer of vibration use the four rubber mounts supplied.

Drain

Install the unit with a positive fall to the front to ensure condensate and/or rain water drains away freely through the drain holes provided. For a totally drip free installation mount the unit in a separate drain tray.

REFRIGERATION PIPING

General

The OSA 147R is shipped with a refrigerant charge sufficient for a 10 m line length. The matched indoor unit is shipped with a holding charge of nitrogen. OSA 147R units have one flare and one brazed pipe connection.

Recommended Pipe Sizes

Suction pipe : 22 mm OD
Liquid pipe : 13 mm OD

Line Lengths

Maximum line length is 50 m, with additional oil required beyond 30 m (refer *Oil Charge* overleaf).

For line lengths beyond 50 m a suction accumulator with 24 hr heating is required; refer to **temperzone** for correct sizing.

Height Separation Limits

Outdoor Unit above Indoor Unit : 12 m
Outdoor Unit below Indoor Unit : 12 m

Vertical Risers

If the outdoor unit is to be installed above the indoor unit, then the suction riser should be trapped at the bottom of the vertical rise and then again at 5 m (maximum) intervals. This is to ensure oil return to the compressor. The trap to be a 'swan neck' curve in the pipe, with no change in the pipe size.

Piping

1. Use clean sealed refrigeration grade piping.
2. Cut pipe with a pipe cutter **ONLY**.
3. Use long radius bends (2x pipe dia.).
4. Insulate the suction (gas) line and seal all insulation joints.
5. Bi-flow filter dryers may be fitted in the liquid line.
6. Include a process point in the interconnecting pipework.
7. Ensure open pipe ends are sealed until the final connection is made.
8. **Caution:** To avoid damage to teflon seals, braze suction pipework to stub connection (supplied loose) **before** connecting to unit's valve.
9. Remove valve's dust cap and lubricate teflon seal with refrigeration oil prior to final assembly and connection.

Charging

The unit is supplied with 4.0 kg of refrigerant HCFC-22 (R22) which is sufficient for up to 10 m of pipework between the indoor and outdoor units. Add 60 g of HCFC-22 per metre above 10 m.


Procedure:

1. Evacuate Indoor Unit and interconnecting pipework to a pressure of 500 microns and hold for 15 mins.
2. Add refrigerant, if needed, via the Schraeder connection on the smaller of the Outdoor Unit's two service valves.

continued...


Dimensions (mm)

OSA 147R



Not to Scale

Net Weight 140 kg



- Open the service valve at the Outdoor Unit to allow refrigerant to flow throughout the system.
- Leak check all brazed and fitted joints.

IMPORTANT :

Step 8 of the 'Start Up Procedure' requires you to check that the superheat on the suction line (where it enters the Outdoor Unit) is between 3°C – 5°C on cooling cycle with an indoor air temperature in the range 21° – 27°C and outdoor air temperature in the range 24° – 35°C. If the conditions of the day do not allow this, use the heating cycle (on a reverse cycle unit) or other heat source to raise the indoor air temperature to about 24°C. Return to cooling cycle and blank off the outdoor coil to raise the head pressure to 240–280 psig (1750–1950 kPag). Alter charge up or down to establish correct superheat.

WARNING:

This unit is designed for use ONLY with the refrigerant HCFC-22. The use of other refrigerants is NOT authorised or approved by the manufacturer and may cause operational problems such as poor performance and efficiency, loss of capacity, degradation of materials and refrigerant leaks. **The use of flammable or explosive materials as a refrigerant creates the additional risks of fire and explosion which may result in property damage, personal injury or death.**

Oil Charge

For line lengths in excess of 30 m, *Emcarate RL22CF* polyol ester oil (or similar) should be added to the refrigerant at the rate of 13 ml/m of suction piping. **Note:** Do not use mineral oil.

ELECTRICAL REQUIREMENTS

Electrical work must be done by a qualified electrician. The outdoor unit must be wired directly from a distribution board by means of a circuit breaker or H.R.C. fuse, and a mains isolator provided - preferably close to the Outdoor Unit.

Note: DO NOT USE REWIRABLE FUSES.

The outdoor unit requires a minimum line voltage 210V at startup.

Minimum supply cable required for:-

- Lengths up to 25 m: 6 mm²
- Lengths above 25 m: 10 mm²

It is recommended electricians run two spare wires between Outdoor Unit and Indoor Unit in case one, or both, of the following options becomes a requirement.

Note: Leave the wires unconnected until required.

Option 1 - Indoor Fan Off During De-Ice (Not required when using **temperzone** HAN-L6 Wall T/stat).

Option 2 - Electric Boost Heat.

Refer indoor unit's wiring diagram.

If electric heat is to be installed then it is recommended it be powered by a separate 25 A fused supply line sourced via a two pole isolator on the Outdoor Unit.

Standard units are suitable for use with thermostats with either manual Heat/Cool selection or automatic changeover subject to the contact ratings of the thermostats. Refer to separate pamphlet for approved thermostats, or contact the manufacturer's nearest sales office.

A 24 hour power supply to the crankcase heaters is required, otherwise the warranty is void.

SYSTEM CHECK TESTS

- Leave the remote switch in the off position and close the mains isolating switch.
A four hour delay period is required to allow the crankcase heater to drive any liquid refrigerant out of the compressor oil.
- Check that all fan motors are free running.
- Check that the thermostat is correctly wired to the unit and is set at the desired temperature.
- Check that the air filters, if any, have been correctly installed.
- Check any supply air diffuser dampers are open.

START UP PROCEDURE

Use the supplied Commissioning Sheet to help you complete the following procedure:

- Switch on the unit after the four hour delay period for the crankcase heater has expired.
- Check the supply voltage.
- Measure the current draw on the compressor motor and on each fan motor. Check all readings against the specified values - particularly the indoor fan amps if the unit is installed in a free blow application.
- Fit gauges and measure the suction and discharge pressures.
- Test the operation of the high pressure safety control by switching off the outdoor unit's fan.
- Test the operation of the reversing valve by running the unit in both the heating and cooling mode.
- Check that the air flow over the outdoor unit's coil is adequate and that the fan is running smoothly.
- Check the superheat - refer charging procedure.
- Check the supply air flow at each outlet.
- Touch up any outdoor unit paintwork damage to prevent corrosion.

OUTDOOR UNIT CONTROLLER (OUC)

The Outdoor Unit Controller (OUC) includes a temperature sensing head pressure control which enables the system to run efficiently on cooling cycle at outdoor ambient temperatures below 20°C, and heating cycle above 15°C. The OUC also has features which protect against icing or overheating of coils, rapid cycling of the compressor and loss of refrigerant charge.

If the outdoor unit fans take some time to begin rotating when the system is powered on, or they don't appear to be rotating appropriately while the compressor is running, consult the OUC label on the electrical box. If necessary, refer to **temperzone** for further diagnostic information.

MAINTENANCE

Weekly For First Four Weeks

- Check indoor unit air filters (if fitted) and vacuum or wash clean as necessary.
- Check condensate drain for free drainage.
- Check compressor compartment for oil stains indicating refrigerant leaks.
- Check tightness of electrical connections.

Six Monthly

- Check the tightness of all fan and motor mountings.
- Check tightness of electrical connections.
- Check that fan motors are free running.
- Check suction and discharge operating pressures.
- Replace indoor unit air filters (if fitted).
- Check condensate drain for free drainage.
- Check Schraeder valve service access port end caps are tight.

Yearly

- Check all refrigerant piping for chafing and vibration.
- Check the operation of electric heaters if fitted.
- Check air supply at all diffusers.
- Check for excessive noise and vibration and correct as necessary.
- Check for insulation and duct damage and repair as necessary.
- Remove lint and dust accumulation from outdoor coil fins.
- Touch up any outdoor unit paintwork damage to prevent corrosion.

NOTE

The manufacturer reserves the right to change specifications at any time without notice or obligation. Certified dimensions available on request.

This pamphlet replaces the previous issue no. 2523 dated 08/05. Oil charge.

**Pipe Length Capacity Loss
On Cooling Cycle Due to Pressure Drop**

Note : Loss percentages are approximations only, due to piping variations. No allowance made for vertical piping.

Pipe Size (mm)		Equivalent Line Pipe Length (m)						Additional Pipe Length to allow per Bend		
Liquid	Suction	10	15	20	30	40	50	Suction Pipe Size OD	22 mm	28 mm
13	22	2.1 %	3.4 %	4.7 %	6.1 %	8.5 %	11 %	Long 90° Radius (i.e. 2 x pipe dia.)	0.5 m	0.6 m
13	28	1.2 %	1.8 %	2.5 %	3.6 %	4.8 %	6 %			

OUTDOOR UNIT :- OSA 147 R
 WITH INDOOR UNIT
 CAPACITIES - NET TO AS/NZS 3823
 COOLING - kW 14.00
 HEATING - REVERSE CYCLE kW 14.90
 ELECTRICAL INPUT
 COOLING - kW 5.35
 HEATING - REVERSE CYCLE kW 4.40
 E.E.R. (COOLING) kW/kW 2.62

ELECTRICAL
 SUPPLY REQUIRED 1PH 210-252V ~ 50HZ INCLUDING VOLTAGE FLUCTUATION LIMITS
 COMPRESSOR (1PH) RUN AMPS RATED CONDITIONS A 21.3
 COMPRESSOR (1PH) STARTING AMPS A 34
 COMPRESSOR CAPACITOR RUN MFD 50
 INDOOR FAN MOTOR (1PH) FULL LOAD AMPS A 5.02
 INDOOR FAN MOTOR CAPACITOR MFD 15
 OUTDOOR FAN MOTOR (1PH) FULL LOAD AMPS A 0.37 x2
 OUTDOOR FAN MOTOR CAPACITOR MFD 3 x2
 RUNNING AMPS (TOTAL) A 25
 RECOMMENDED EXTERNAL FUSE SIZE A 45

WEIGHT - NET OSA 147 R 134kg
 REFRIGERANT -
 UNIT PRECHARGED (10 METRE LINE LENGTH) 4.0 kg
 BASE CHARGE UNIT 3.4 kg PLUS 60 grams PER METRE LINE LENGTH
 BASED ON ø12.7 OD LIQUID LINE & ø22 OD GAS LINE

ABB	DESCRIPTION	ABB	DESCRIPTION
CAP	CAPACITOR	OFR	OUTDOOR FAN RELAY
CM	COMPRESSOR MOTOR	OFCR	OUTDOOR FAN RELAY COIL
CCH	CRANKCASE HEATER	RV	REVERSING VALVE
HP	HI PRESSURE CONTROL	SS	SURE START
OFM	OUTDOOR FAN MOTOR		

Consult Outdoor Unit Controller label for further details, or refer to Temperzone for fault diagnosis information.
 Sensor Locations:
 Red to service valve pipe pocket.
 Yellow to coil return bend pocket.
 Blue to bottom of coil in fins.

CHECK WIRING BEFORE SWITCHING ON.
 INCORRECT CONNECTION WILL DAMAGE MOTORS

CLIENT WIRING
 Interconnections between units by client.
 Double insulated multi-core cable.

Programmed by


Title OSA 147R
 WIRING SCHEMATIC

tempertone

Drawn D.A.B Date 29-09-03 Drawing No. 426-334-002 Revision A
 Scale *Apd*

PLOTTED
 27-02-04
 ©temperzone ltd
 2003

TO THE ELECTRICIAN
 THIS UNIT REQUIRES A MINIMUM LINE VOLTAGE OF 210V AT STARTING LOAD. MINIMUM SUPPLY CABLE 6mm² UP TO 25 METRES. MINIMUM SUPPLY CABLE 10mm² ABOVE 25 METRES. INDOOR UNIT POWER SUPPLY MUST BE OFF ACTIVE IN OUTDOOR UNIT (SAME PHASE)



ISSUE	MODIFICATION	ECN	DATE	APPRD	DRG SIZE	No.	DESCRIPTION	Mat.l	FINISH	ASSY No.
A	RELOCATE COMPRESSOR WIRES	1188	10-08-05	ROD						

