

APPLICATIONS NOTICE

temperzone limited
Auckland, NEW ZEALAND.
Phone 0-9-279 5250, Fax 0-9-275 5637
Email sales@temperzone.co.nz

temperzone australia pty ltd Sydney, AUSTRALIA. Phone (02) 8822 5700, Fax (02) 8822 5711 Email sales@temperzone.com.au

TO:

AUTHORISED DEALERS/DISTRIBUTORS

N.Z. APPROVED INSTALLERS H.O., REG'L & AUST. MANAGERS APPLIC. NOTICE GENERAL LIST ISSUE NO.: 01/01

DATE:

11 January 2001

FROM:

C SNELL/K EDWARDS

Form NS 006

SUBJECT:

RETURN AIR SPIGOTS

UNITS:

HWP33, 41 & 49

DUCTED WATER COOLED PACKAGED AIR CONDITIONERS

The HWP33-49 pamphlets do not include dimensional data on return air spigots. This is because the unit was primarily designed for applications where return air comes from the ceiling space, however we appreciate there will be applications where a return air duct may be required.

Should your HWP units need return air ducting the dimensions of a suitable spigot are shown in the attached drawings. temperzone does not offer return air spigots on HWP33-49, therefore the installer would have to arrange for them to be made elsewhere.

To install your return air spigot, proceed as follows:

- 1. Remove the HWP unit's return air filter from its track and put aside.
- 2. Unscrew the top filter track from the HWP unit.
- 3. Replace the filter track screws in their original holes, as these hold more than just the filter track in position.
- 4. Attach a strip of 5mm thick Inseal to the back of the spigot. This will ensure an air tight seal between the spigot and the HW unit.
- 5. Use four No. 8 x 12 1g screws and the holes provided to secure your spigot to the HW unit.
- 6. The filter supplied with the HW unit will fit into the return air spigot, providing it has been made to the supplied dimensions.

