

OPA 201RKTYGH (Digital c/w EC motor and UC7 Controller)

Packaged Reverse Cycle R410A Air Cooled Air Conditioner

Installation & Maintenance

GENERAL

This OPA 201 unit must be installed in accordance with all national and local safety codes.

OPTIONS (Field Fitted)

1. TZT-100 Room Temperature Controller
2. Signal Isolator (refer Indoor Fan Speed control options).

INSTALLATION

Positioning

Refer to dimension diagram for minimum clearances. If multiple units are to be placed side-by-side then allow at least 2 m between coil faces.

Mounting

Fasten the unit down to a firm flat horizontal base using the four holes provided in the mounting rails.


When the unit is being installed on a roof it is recommended that the unit is installed on a substantial structure with vibration isolating springs beneath the unit. These springs are not supplied with the unit.

Flexible duct connections are recommended between the supply and return ducts and the unit.

Condensate Drain

The condensate drain should be 'U' trapped outside the unit. The trap should have a vertical height of at least 50 mm. The drain should have a slope of at least 1 in 50 and must not be piped to a level above the unit drain pipe.

For long condensate pipe runs, fit a vent pipe near the drain trap. The top of the vent pipe must be at least 100 mm above the OPA unit's drain tray.



REFRIGERATION SYSTEM

General

The refrigeration system has been charged with R410A refrigerant; refer wiring specification table for amount. Tapping points are provided to measure discharge and suction operating pressures. Beware of high system pressures; use correct gauges.

Compressor

The compressor is digital scroll type. This has a variable capacity ability that enables closer control of room temperature.

The compressor lubricant is polyol ester oil (POE). Note, this oil absorbs moisture quickly if exposed to open air.

ELECTRICAL REQUIREMENTS

Electrical work must be done by a qualified electrician. The outdoor unit must be wired directly from a distribution board by means of a circuit breaker and a mains isolator provided - preferably close to the unit.

Standard units are suitable for use with thermostats with either manual Heat/Cool selection or automatic changeover subject to the contact ratings of the thermostats.

The system is set up for the compressor to be controlled variably by:

1. TZT-100 Controller (via RS485 modbus),
2. 0-10V dc command via BMS modbus, or
3. 0-10V dc command via a client supplied external controller.

If option 1 is chosen, then disconnect or remove the Signal Input for Controller 0-10V.

If a TZT-100 Controller is used then variable capacity control is automatically included and no additional wiring is required.

Note: The TZT-100 Controller can automatically switch the indoor fan off during de-ice, if selected, therefore no additional wiring is required to achieve this result.

A 24 hour power supply to the crankcase heaters is required, otherwise the warranty is void.

INDOOR FAN SPEED

The indoor fan speed can be 'Stepped' or 'Continuously Variable'. The choice is made using Switch 1 of 'DIP1' on the EC Motor Controller. Switches 1 to 5 on 'DIP2' determine the minimum and maximum fan speeds.

The same 'Minimum rpm' and 'Maximum rpm' settings apply to 'Stepped' and 'Continuously Variable'.

The default settings for DIP1 and DIP2 are highlighted on the Wiring Schematic.

1. *Stepped (DIP1 switch 1 = OFF)*
Connecting the 24V AC power from the unit's 'HOT 24V' terminal to one (and only one at a time) of the 'LOW 24V' / 'MED 24V' / 'HIGH 24V' terminals, selects the 'LOW' (Min. rpm), 'HIGH' (Max. rpm), or 'MED' (mid-way between) fan speed. The transitions between speeds are smooth.
2. *Continuously Variable (DIP1 switch 1=ON)*
When using this method a temperzone analog Signal Isolator (No. 201-000-129)

must be fitted and connected as shown in the wiring schematic. 24V AC or DC power from the external (BMS) controller should be provided to the '24V' and '0V' input terminals of the Signal Isolator board.

A voltage below 2V DC applied across the '0V' and the '0-10V' input terminals (labelled 'From BMS Controller' in the wiring schematic) of the Signal Isolator will stop the indoor fan. A control voltage of slightly more than 2V will cause the fan to run at the 'Min. rpm' speed. A 10V DC signal will run the fan at the 'Max. rpm' speed. Control voltages between these two limits can be used to achieve any desired speed between 'Min.' and 'Max.' rpm.

Do not use switch combinations marked with 'DO NOT USE' in the Speed Selection table.

If the air returning to the indoor unit is regularly expected to be above 50%RH, then the coil face velocity should be limited to be 2.5 m/s or less (refer Air Handling graph in Technical Data pamphlet).

High humidity levels can occur in tropical or subtropical conditions, and/or when heavily moisture laden fresh air is introduced. Select a fan speed that avoids water carry-over problems.

CHECK TESTS

1. Leave the remote switch in the off position and close the mains isolating switch.
A four hour delay period is required to allow the crankcase heater to drive any liquid refrigerant out of the compressor oil.
2. Check that all fan motors are free running.
3. Check that the thermostat is correctly wired to the unit and is set at the desired temperature.
4. Check that the air filters, if any, have been correctly installed.
5. Check any supply air diffuser dampers are open.

START-UP PROCEDURE

Use the supplied Commissioning Sheet to help you complete the following procedure:

1. Switch on the unit after the four hour delay period for the crankcase heater has expired.
2. Check for correct rotation of the compressor. If rotation is incorrect the compressor will not pump, be noisy, and will draw minimal current. To correct motor rotation, change the phasing at the main power terminal.

3. Check the supply voltage.
4. Measure the current draw on the compressor motor and on each fan motor. Check all readings against the specified values - particularly the indoor fan amps if the unit is installed in a free blow application.
5. Fit R410A compatible gauges and measure the suction and discharge pressures.
6. In cooling mode, test the operation of the high pressure safety control by safely disconnecting the outdoor air fan.
7. Test the operation of the reversing valve by running the unit in both the heating and cooling mode.
8. Check that the motors are running smoothly.
9. Check the supply air flow at each outlet.
10. Touch up any outdoor unit paintwork damage to prevent corrosion.

UNIT CONTROLLER (UC7)

The Unit Controller provides system protection functions such as coil frost protection, de-icing, high head pressure and low suction pressure cut-out. It also protects against rapid cycling of the compressor(s) and loss of refrigerant. Various methods of head pressure control (or limiting) are employed in temperzone units. The particular method used varies from model

to model, but is also handled by the Unit Controller. In combination, these features deliver optimised performance across a wide operating temperature range.

As a result of the UC's control of these inter-related functions, the outdoor fans may take some time to start rotating after each compressor start. They may also run on when the compressor stops. The fans will stop during a de-ice cycle. The speed will vary either smoothly, or in steps, in order to protect against excessively low or high head pressure.

Refer to UC7 Controller label on the unit or www.temperzone.biz for operation & fault diagnostics information; model search 'UC7'.

MAINTENANCE

Weekly For First Four Weeks

1. Check indoor air filters (if fitted) and vacuum or wash clean as necessary.
2. Check condensate drain for free drainage.
3. Check compressor compartment for oil stains indicating refrigerant leaks.
4. Check tightness of electrical connections.

Six Monthly

1. Check the tightness of all fan and motor mountings.

2. Check tightness of electrical connections.
3. Check suction and discharge operating pressures.
4. Replace indoor unit air filters (if fitted).
5. Check condensate drain for free drainage.

Yearly

1. Check all refrigerant piping for chafing and vibration.
2. Check the operation of electric heaters, if fitted.
3. Check air supply at all diffusers.
4. Check for excessive noise and vibration and correct as necessary.
5. Check for insulation and duct damage and repair as necessary.
6. Remove lint and dust accumulation from outdoor coil fins.
7. Touch up any outdoor unit paintwork damage to prevent corrosion.

NOTE



Specifications are subject to change without notice due to the manufacturer's ongoing research and development programme.

This pamphlet replaces the previous issue no. 3961 dated 04/13. Wiring revision B, RA spigot dim.



Dimensions (mm)

OPA 201RKTYGH

Not to Scale



POINT LOADS (kg)				WEIGHT (kg)
W	X	Y	Z	
50	60	88	72	270




Capacities - Net to AS/NZS 3823	OPA201RKTYGH
Cooling -	KW 19.76
Heating - Reverse Cycle	KW 18.08
Electrical Input	
Cooling -	KW 6.12
Heating - Reverse Cycle	KW 5.42
E.E.R. (Cooling)	KW/KW 3.140
A.E.F.R. (Cooling)	KW/KW 3.126
Electrical	
Supply required 3Ph 342-436V ~ 50Hz Including voltage fluctuation limits	
Compressor type: Scroll	
Compressor (3Ph) run amps rated conditions	A/Ph 8.6
Oil type: Polyester (P.O.E.)	
Indoor fan motor (1Ph) Full load amps	KW 1.25
Indoor fan motor (1Ph) Full load amps	A 8
Outdoor fan motor (1Ph) Full load amps	A 3.0 x 1
Outdoor motor capacitor (Built in fan motor)	MFD 12
Running amps (Total)	A/Ph 13.0/8.6/8.6
Max running amps (Total)	A 24
Control circuit breaker	A 16
Unit Weight - Nett	kg 265
Base charge unit	kg 6.3

CAP Capacitor	LP	Low Pressure Control
CCB Control Circuit Breaker	MV	Modulating Valve
CCH CrankCase Heater	OFM	Outdoor Fan Motor
CM Compressor Motor	PRC	Phase Rotation Control
CNC Compressor Contactor	PRR	Phase Rotation Relay
FRB Fault Relay Board	RV	Reversing Valve
HP High Pressure Control	TFC	Triac Fan Controller
IFM Indoor Fan Motor	UC7	Unit Controller 7

UC7 Dip switch settings	
DIP switch	↑ On/Off ↓
1,2,4 & 6	On
3,5,7,8,9,10,11,12,13,14,15 & 16	Off

Temperature Sensor	
Sensor	Color
DL Discharge	Red
IC I/D Coil	Yellow
AMB Ambient	Black
DEI Deice	Blue
OC O/D Coil	Yellow

TFC SW2 (DIP S/W) settings	
DIP	On/Off
1,2,3 & 4	Off



Title **OPA 201RKTYGH WIRING SCHEMATIC**

temperzone

Drawn A.F.C. 25-10-12
 Approved 2015
 Drawing No. 291-000-308
 Revision B

Client wiring -----

Visit: www.temperzone.biz for client wiring diagrams

Issue MODIFICATION

B	Fan motor & controller changed	ECN	DATE	APRVD
B	All 24v components removed. CCB was 10A.	N556	31-07-14	KTT

Disconnect 0-10V Compressor capacity board when connecting TZT-100 Thermostat

