



# OPA 171/211 RLTFY (Econex)

## Air Cooled Packaged Units - Reverse Cycle - R32

### Installation & Maintenance

#### CONTENTS

	Page
1. GENERAL .....	1
2. INSTALLATION .....	2
3. REFRIGERATION SYSTEM.....	2
4. WIRING .....	3
5. START-UP PROCEDURE .....	4
6. OPERATION.....	5
7. MAINTENANCE.....	5
8. TROUBLESHOOTING .....	6
9. WARRANTY .....	6
APPENDIX I : UC8 PROTECTION FUNCTIONS.....	7
APPENDIX II: UC8 INFORMATION DISPLAY .....	9
APPENDIX III: AIR HANDLING PERFORMANCE .....	10
APPENDIX IV: CONNECTION WIRING PATHS.....	10
COMMISSIONING CHECK LIST .....	11

#### 1. GENERAL

Follow these instructions to ensure the optimum performance, reliability and durability of your Temperzone OPA Outdoor Air Cooled Packaged unit.

Units must be installed in accordance with all national and regional regulations and bylaws. National Health and Safety regulations must be followed to avoid personal injuries.

The appropriate local permits must be acquired and adhered to.

Local regulations on maximum boundary noise need to be considered when positioning the unit.

The accompanying 'R32 Handling Ducted Packaged Units' pamphlet forms part of these Installation & Maintenance instructions.

##### **⚠ WARNING**

**These units use R32 refrigerant (Class A2L) which is mildly flammable.**

The system shall be installed, operated and stored in a well ventilated space. If the refrigerant gas comes into contact with fire, a poisonous gas may occur. Be aware that R32 does not contain an odour.

If indoors, the appliance shall be stored in a room away from continuously operating sources known to cause ignition of R32 refrigerant (for example an operating gas appliance or operating electric heater)

This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

#### 2. INSTALLATION

##### 2.1 Location, Clearances & Service Access

Units should be located in a place that is not accessible to the general public. Refer to Specification Sheet supplied for minimum clearances. If multiple units are to be placed side-by-side then allow at least 2m between coil faces.

##### *Plant Room Installation (Option)*

Ensure sufficient ventilation is installed. Discharge air from above the unit must be ducted away to prevent recirculation of air through the unit. Restricted airflow and/or recirculation reduces efficiency. Never install the unit in a totally enclosed room.

##### 2.2 Mounting

The unit should be fastened to a firm flat horizontal base (indoors or outdoors) using the holes supplied in the mounting channels. When the unit is being installed on a roof it is recommended that the unit is installed on a substantial structure with vibration isolating pads or mounts. If placed on the ground or concrete pad, use rubber pads or mounts to give 20mm min. ground clearance.


Flexible duct connections are recommended between the supply and return ducts and the unit.

The unit is shipped with plastic wedges installed under the compressor. Ensure these wedges are removed from the compressor feet prior to starting the unit (not required for operation).

### 2.3 Condensate Drains

Condensation can form on both the indoor and outdoor air coils. This is normal during unit operation. It is recommended the condensate be piped to a suitable drainage point to prevent ponding and/or slippery mould growth around the base of the unit.

The condensate drains should be 'U' trapped outside the unit. The traps should have a vertical height of at least 100 mm. The drain lines should have a slope of at least 1 in 50 and must not be piped to a level above the unit drain pipe.



## 3. REFRIGERATION SYSTEM

### 3.1 General

Each OPA 171/211 has a single refrigeration system using a variable speed inverter compressor and is charged with R32 refrigerant; refer Specifications document for amount.

### 3.2 Compressor

The compressor is an inverter scroll type. The compressor lubricant is polyolester oil (POE). Note, this oil absorbs moisture quickly if exposed to open air.

## 4. WIRING

### 4.1 Electrical Requirements

Electrical work must be done by a qualified electrician and meet standard AS/NZS 3000.

**⚠ DANGER! LIVE ELECTRICAL CONNECTIONS. ISOLATE MAINS POWER BEFORE WORKING ON UNIT. ONLY QUALIFIED PERSONS WHO ARE COMPETENTLY TRAINED SHOULD PERFORM SERVICE AND MAINTENANCE TASKS.**

The unit must be wired directly from a distribution board using an appropriately sized circuit breaker. The termination point for the mains cable is in the electrical compartment. A lockable isolating switch is required, near but not on the unit.


Refer Appendix IV (p.10) for cable entry hole locations and recommended wiring paths.

A 24 hour power supply to the compressor crank case heaters is required, otherwise the warranty is void.

### 4.2 Unit Controller (UC8)

The unit's UC8 controller receives requests such as 'Unit On/Off', 'Start compressors', 'Activate HEAT (Reverse Cycle)' and transfers the requests to the outputs after enforcing safety timers.

Figure 4. UC8 Controller



Each Unit Controller provides several system protection functions. These are covered in Appendix I (p.9).

For additional information, refer to the UC8 Controller label on the unit or [www.temperzone.biz](http://www.temperzone.biz) for operation & fault diagnostics information; model search 'UC8'.

References available:

UC8 Fault & Display Messages (as per unit label)

UC8 Quick Reference and Operation Fault Diagnosis

UC8 Troubleshooting Guide

UC8 Modbus Communications

UC8 BACnet Communications

UC8 Master-Slave Connection

### 4.3 External Control options

OPA Econex units can be controlled using any one of the following options:

- TZT-100 wall thermostat** (Note: Not suitable for units supplied with Economiser dampers), or
- BMS Low Level:** 12–24V ac/dc and 0–10V dc signals from an external controller or thermostat, or
- BMS High Level:** Modbus RTU serial communications over RS485 connection, or BACnet/IP serial communications over ethernet connection (with optional gateway module).

Each of these can work in conjunction with other auxilliary control features, eg remote on/off switch and/or time clock

A unit wiring diagram is supplied alongside the electrical board and in the Specifications document.

### 4.4 TZT-100 wall thermostat


#### 4.4.1 Connection

To connect the thermostat to the unit, use 4 core shielded twisted pair type cable, suitable for RS485 communications. (p/n 201-000-399). Signals A and B should form one twisted pair.

**Note:** The cable shield should connect to terminal '0V' on the UC8 controller only. Do not connect at both ends.

Connect the thermostat as follows:

#### TZT-100 Connection:



Note: **Capacity Staging.** A TZT-100 must be configured for single-stage operation, **the default setting.**

TZT-100 has its own DIP switches that must be set as follows:

<b>DIP switch 2</b>	ON	Equipment type = Heat Pump
<b>DIP switch 3</b>	OFF	Equipment stages = One
<b>DIP switch 4</b>	ON	Reverse cycle valve on = Heating

The UC8 master controls the staging of the compressors.

#### 4.4.2 Communications format for TZT-100

Communications format must be set as per recommended Modbus RTU:

- Baud rate (bd or br) 19200
- Data bits 8
- Parity Even
- Stop bits (Pa) 1
- TZT-100 address (Ad) 7

The procedure to check and adjust these settings is:

1. Press and hold the O/RIDE button until the display shows the PIN
2. Use the UP & DOWN buttons to select PIN code 88:21, then press O/RIDE in installer mode.
3. Use the O/RIDE and PROG buttons to cycle through the various installer settings.

If necessary, refer TZT-100 User Manual for more detail.


#### 4.5 Remote on/off

The UC8 has an input for a remote on/off function on terminal 'On', signal return is terminal '0V'. When used the remote on/off terminals should connect to a voltage-free relay contact. When not used the remote on/off terminals should be shorted ('bridged').

#### 4.6 Control using switched and 0-10V signals

An external controller that provides 12/24V ac/dc switched signals or has a set of voltage-free relay contacts should be connected as per the general diagram below. Refer Specifications document for detailed wiring (sheet 4)

Figure 5. BMS connection




For variable fan capacity control use the 'FAN IN 0-10V' terminal.

If no variable fan capacity control required, use one or all of the three speed options LOW/MED/HIGH available.

#### 4.7 Control via Modbus RTU communications

##### 4.7.1 Connection

OPA Econex units can be fully monitored and controlled via Modbus RTU serial communications.



The following is typical for most installations:

- Set DIP switches 11 and 12 to OFF on UC8 controller.
- Connect BMS terminal A / TX+ to terminal A1 on the UC8 controller via terminal block shown.
- Connect BMS terminal B / TX- to terminal B1 on the UC8 controller via terminal block shown.

##### 4.7.2 Setting the UC8 Modbus device address

To view or change the Modbus device address of a UC8 follow these steps:

- Power up the unit but leave the compressor off.
- Hold down the SW3 pushbutton on the UC8 circuit board until the display shows:  
'0' [release] → '1' → short press to '2,' [long press] → A, [long press]
- The display will show the current Modbus device address. The factory default address is '44'. [Short press] the button to select higher numbers, for example press once to change the address to 45, press twice for address 46 and so forth. [Long press] to save the chosen address. After address 99 the number returns back to 1.
- The controller returns to the default state (– ●).

##### 4.7.3 Multiple OPA Units

Multiple OPA units can be daisy-chained together. For detailed information about monitoring and control via Modbus RTU refer to document 'UC8 Modbus communications', available at [www.temperzone.biz](http://www.temperzone.biz) (model search 'UC8') or [temperzone.com](http://temperzone.com) website.

#### 4.8 Control via BACnet/IP communications

A BACnet connection is available using *Babel Buster 3* network gateway module. For information regarding using BACnet commands, please ask Temperzone.

### 5. START-UP PROCEDURE

#### 5.1 Before starting the compressor

1. Before working on the unit remove mains power from the unit by opening the mains isolating switch.
2. Remove the shipping wedges from beneath the compressor. Check that the compressor is securely mounted.
3. Check the thermostat and/or other controls are correctly wired to the unit.
4. Check tightness of electrical connections.
5. Check external air filters (not supplied) have been correctly installed. (Filters must be installed before starting the unit.)
6. Check that all indoor fan motors can freely rotate.
7. Check the supply voltage between each phase and neutral.
8. Apply mains power to the unit by closing the mains isolating switch.


9. Air Balance the building's ducting system using an experienced HVAC technician. This will require temporary isolation of the compressor using the internal circuit breaker, and running the fan only. (Refer 5.2 for fan speed considerations)
10. Once Air Balancing is complete, power OFF the unit and reset the compressor circuit breakers.
11. BEFORE starting the compressors a four hour delay period is required to allow the crankcase heaters to drive any liquid refrigerant out of the compressor oil. Mains power must be switched on during this four hour delay period.

## 5.2 Variable speed (EC) indoor air fan set-up

A unit equipped with variable speed (EC) indoor air fans allows adjustment of the fan speeds to obtain the desired indoor supply airflows.

### 5.2.1 Using TZT-100 option (3-speed set-up)

If the unit is controlled with a temperzone TZT-100 wall thermostat then adjustments are made as follows:

- i. Ensure the compressor is off and the thermostat or BMS does not request for the compressor to start. The UC8 display should show a flashing dot (●).
- ii. To adjust the fan High speed press and hold down the SW3 push button on the UC8 circuit board until the display shows:  
'0' [release] → '1' [long press] → 't'; [short press] repeat to find 'H', then [long press] to select.
- iii. The fan will start and run at High speed. The display shows the fan control voltage for the High speed setting; factory default value is 8.0V. 
- iv. Each following press on the SW3 push button increases the indoor fan control voltage in steps of 0.5V, up to a maximum of 10.0V. Pressing the push button again when value 10.0 is shown returns the fan control voltage down to the minimum value of 3.0V and back up again.
- v. When the desired setting for high fan speed is displayed, [long press] to select and save. The controller then exits the menu and the fan stops.
- vi. To adjust the fan Low speed hold down the SW3 push button on the circuit board until the display shows:  
'0' [release] → '1' [long press] → 't'; [short press] repeat to find 'L', then [long press] to select.  
The fan will start and run at the Low speed setting. The factory default value is 5.0V.
- vii. Repeat steps (iv) and (v) to adjust the fan Low speed setting. The minimum control voltage for Low speed is 1V and the maximum control voltage for Low speed is 8V. (Note: A 'low' control voltage of less than 2V is not recommended.) If 'low' is set higher than 'high', the 'high' is made equal to 'low'.
- viii. Check if the High speed airflow is to specification (refer Note below)

#### Note:

*It is allowed to make the control voltages for low and high fan speed equal. This makes the indoor fan act as a fixed speed fan.*

**5.2.2 External 3-Speed Set-Up using 12/24V signal (BMS)**  
Once BMS is wired to the correct speed terminals (refer 4.7) the Low/Med/High speeds can be adjusted at each UC8 using the same procedure as for TZT-100 above.

**5.2.3 External 0–10V Fan Speed Control (BMS)**  
Once BMS is wired to the FAN IN 0–10V terminal (refer 4.7) the input voltage will be interpreted by the master UC8 as follows:

**BMS Input      Output fan control**

0~0.99 V      0 V (Off)

1.0~1.49 V      0 V or Low level (whichever is currently the case)

1.5~9.5 V      Low level to High level

9.5~10 V      High level

It is not recommended, but the indoor air fan speed can be controlled 'independent' of the UC8 controller by an external source. It is then the responsibility of the HVAC system designer and installer to ensure proper and safe operation of the indoor fan, and the system as a whole, under all operating conditions. Excessive control volts may cause nuisance tripping.

#### ⚠ CAUTION


*Setting the indoor fan speed too low can bring risk of frost forming on the indoor coil with potential nuisance frost protection trips on cooling, possibly even unit lock-out, and/or HP trips on heating.*

*Setting the indoor fan speed too high can bring a risk of drawing moisture off the fins of the indoor coil and into the supply air duct. Water could then start leaking from the supply air grilles and corrosion of ducting may occur. Setting the indoor fan speed too high can also bring a risk of 'over-condensing' (when the unit is heating) which in turn could cause the unit to perform more outdoor coil de-ice cycles than necessary. The unit should not be operated outside of published fan curve parameters*

*Refer Appendix III Air Handling graphs for indoor airflow range.*

## 5.3 Commissioning

After the four hour delay period has expired (see step 11 in section 5.1) complete the following procedure. You can use the Commissioning Sheet (refer p.10) to help you.

1. Place the UC8 controller in commissioning mode by pressing and holding the SW3 push button (see Fig. 4) until the display shows:  
'0' [release] → '1' [long press] → 't'; [short press] repeat to find 'c', then [long press] to select.   
This Commissioning mode 'c' reduces the waiting times at start-up and between cycles for the next half hour, or until the controller is reset by removing power.
2. Start compressor in Cooling mode.
3. Check the outdoor fan motor runs smoothly.  
*Note: The outdoor fan does not necessarily start rotating immediately after the compressor is started. The fans may run-on for a short period after the compressor stops.*  
Outdoor fan stops during outdoor coil de-ice cycles.
4. Measure the current draw on each phase on the compressor motor and to each fan motor. Check the readings against the specified values in the wiring diagram or specification sheet.
5. The display and pushbutton on the UC8 can be used to check temperatures and pressures. Short presses on the pushbutton cycles through the available options. **Table 1** on page 10 shows, in sequence, what information is available – with examples.

Alternatively use a set of pressure gauges suitable for R32 refrigerant.

#### ⚠ WARNING

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. If a leak is suspected, all naked flames shall be removed/extinguished.

If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut-off valves) in a part of the system remote from the leak.

6. Test operation of the compressor when operating in heating mode.



7. Check for desired supply air flow rate at each outlet (if air balancing has not been completed).
8. Touch up any outdoor unit paintwork damage to prevent corrosion.
9. Sign the check label on the Electrical Box cover.

## 6. OPERATION

### 6.1 Safety timers

The UC8 receives control signals and transfers the signals to the outputs after enforcing safety timers and other protection functions. If the compressor is held off, or held on, by a safety timer then the display shows message 'H-O-L-d'.

**HOLD**

Normal durations of safety timers are:

- Minimum off time     3 minutes
- Minimum run time     1.5 minutes
- Min. cycle time        6 minutes (up to 10 compressor starts per hour)
- Min. mode change-over time  
10 minutes (cooling to heating or vice-versa)

### 6.2 Variable Capacity

The OPA unit is equipped with a single variable capacity compressor (inverter scroll type). The inverter compressor operating capacity is 16%–100% using 2V–10V control voltages.

At any time, when operating conditions dictate, system protection functions can restrict unit operating capacity.

When a capacity signal is presented that is lower than the minimum capacity (for example 0V on input 'VC') then the compressor operates on minimum duty.

If a unit operates on low capacity for extended periods then the unit may periodically perform oil flush cycles. Under such operating conditions compressor lubricating oil may slowly settle in parts of the refrigeration system other than the compressor. Oil flush cycles help to return the lubricating oil to the compressor. During an oil flush cycle compressor speed is increased for a duration of 1 minute.

Variable capacity indoor air fan – Refer Section 5.2

**Note:**

*Outdoor fans do not necessarily start rotating immediately after the compressor is started. The fans may run-on for a short period after the compressor stops.*

*The indoor fan will reduce speed if in heating mode and the condensing temperature is too low to automatically allow the condenser coil to warm up.*

If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system.

4. Check system operating pressures via each UC8 controller or using a Temperzone Wifi Service Utility (WSU); pn 201-000-700; refer Appendix I.

### 7.2 Six Monthly

1. Check the tightness of electrical connections.
2. Check for signs of corrosion on electrical connections in high salt atmospheres; replace where necessary.
3. Check the tightness of all fan motor mountings
4. Check system operating pressures via each UC8 controller or using a Temperzone Wifi Service Utility (WSU); refer Appendix I.
5. Check condensate drain for free drainage.

### 7.3 Yearly

1. Check all refrigerant piping for chafing and vibration.
2. Check air supply at all diffusers
3. Check for excessive noise and vibration (compressor, fans, pipework) and correct as necessary.
4. Check for insulation and duct damage and repair as necessary.
5. Check system operating pressures via each UC8 controller, or using a Temperzone Wifi Service Utility (WSU); refer Appendix I.
7. Remove lint and dust accumulation from outdoor coil fins with soft brush or low pressure water spray. In corrosive environments, the checking and cleaning frequency should be increased.
8. Touch up any paintwork damage to prevent corrosion.

## 7. MAINTENANCE

**⚠ WARNING! HAZARDOUS VOLTAGE. ENSURE ALL POWER SUPPLIES ARE ISOLATED BEFORE PERFORMING MAINTENANCE. FAILURE TO ISOLATE POWER CAN LEAD TO SERIOUS INJURY.**

### 7.1 Monthly

1. Check air filters and vacuum, wash clean or replace as necessary.
2. Check condensate drain for free drainage.
3. Check compressor compartment for oil stains indicating refrigerant leaks.

#### **⚠ WARNING**

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. If a leak is suspected, all naked flames shall be removed/extinguished.

---

## 8. TROUBLESHOOTING

### 8.1 Room temperature varies significantly from its setting

- Unit may have been incorrectly sized for the building.
- Drafts from poorly placed supply air diffusers or from the back of the wall plaque could be affecting the temperature sensor built into the wall plaque.
- Poor air circulation in the room can cause incorrect temperature readings.

### 8.2 Air conditioner does not seem to deliver the heating when most needed

- Heating capacity at design conditions may be incorrect. As the outside temperature falls, heat losses through the walls, floor and ceiling increase.
- Check the unit's brochure for information on the minimum/maximum operating temperatures.
- When heating, units have de-icing cycles built-in to remove ice on the outdoor coils. This usually means reversing the cycle on some, but not all systems at once, for a few minutes. Heating may be slightly reduced at this time, but usually not noticeable.

### 8.3 In a new building, why does it take some days before the air conditioning heat pump unit seems to work properly

- Many new buildings, especially commercial buildings, have a large amount of concrete and other structural materials that are generally cold and full of moisture. This is most evident in winter when trying to heat the building from outdoor ambient condition, ie a Cold Start.

### 8.4 Unit is spitting or leaking water

- It is normal for the unit to produce condensation when heating and cooling. Check the drain trap/vent/slope for free drainage.
- Water carry-over: Reduce the maximum fan speed. Refer Appendix III for indoor airflow range.
- Check any external fresh air damper is not opened by BMS when raining outside. A humidity sensor could prevent this.

### 8.5 Air conditioner runs excessively – the temperature remains too hot in summer or too cold in winter

- Windows or doors may be opened to non-conditioned areas.
- Keep doors to unconditioned areas closed.
- Leaves, papers or other items blocking air flow over the outdoor unit coil.
- Location of wall controller or remote temperature sensor is incorrect.
- Check for air leaks in supply or return air ductwork.

### 8.6 Unit displays an error code:

- Refer to UC8 Controller label on the unit for operation & fault diagnostics information or visit [www.temperzone.biz](http://www.temperzone.biz); model search 'UC8 Controller'.
- A 'Temperzone Service Tools' app for smart phones is available to help diagnose problems. It is a free download from the *App Store*® or *Google Play*® or visit <https://servicetools.temperzone.com>

---

## 9. WARRANTY

Please refer to the separate warranty document supplied with the unit, or visit [www.temperzone.com](http://www.temperzone.com) for details.

Australia:

[warranty@temperzone.com.au](mailto:warranty@temperzone.com.au)

[spares@temperzone.com.au](mailto:spares@temperzone.com.au)

Telephone: 1800 21 1800


New Zealand:

[customerservices@temperzone.co.nz](mailto:customerservices@temperzone.co.nz)

Telephone: 0800 TZWARRANTY (899 2777)

## APPENDIX I

### UC8 PROTECTION FUNCTIONS



Each OPA Econex unit utilises up to four UC8 Controllers, one for each refrigeration system. The UC8 controllers receive requests from the Master Controller such as 'Unit On/Off', 'Start compressors', 'Activate HEAT (Reverse Cycle)' and transfer the requests to the outputs after enforcing safety timers.

Each UC8 implements system protection functions such as indoor coil frost, extreme high and low pressures, rapid on-off cycling of the compressors, loss of refrigerant and more.

The following applies to all protection functions except where otherwise indicated:

Unit operating capacity may automatically be reduced before a protection function is activated. Such a reduction may be sufficient to prevent an actual trip from occurring.

When a compressor is stopped by a protection function it is held off for a period of 3 minutes, after which it is allowed to restart (provided the cause of the trip has cleared).

When a protection function is active and when a unit is locked out the alarm relay output "FLT" is active.

For more information about protection functions and troubleshooting, refer to document "UC8 Troubleshooting", available at [www.temperzone.biz](http://www.temperzone.biz) website; model search 'UC8'.

#### 1 High pressure protection (HP)

OPA Econex units are fitted with high pressure transducers connected to UC8 input HPT. A compressor is switched off when the discharge line pressure is too high and risks damage to the compressor and pipework

The display shows the letters 'HP' when protection is active.

HP

#### 2 Low pressure protection (LP)

OPA Econex units are fitted with low pressure transducers connected to UC8 input LPT. A compressor is switched off when the suction line pressure is too low and risks damage to the compressor. Possible refrigerant leak..

The display shows the letters 'LP' when protection is active.

LP

#### 3 Indoor coil frost protection

When the unit is cooling the evaporating temperature in the indoor coil should remain above -8°C. If this temperature falls below -8°C then ice (frost) likely will form on the indoor coil. If the low temperature persists for longer than 6 minutes then the protection function activates.

When indoor coil frost protection is activated the compressor is stopped for 6 minutes, after which it is allowed to restart.

Hi-8

#### 4 High discharge line temperature protection

The controller monitors the compressor discharge line temperature via a sensor connected to input 'DL' (grey wires). The compressor is stopped when:

- The temperature rises above 115°C for longer than 15. minutes.
- The temperature rises above 125°C (immediate action).

The display shows the message 'Hi-t' when protection is active.

Hi-t

#### 5 High discharge superheat protection

Discharge superheat is defined as the difference between the compressor discharge gas temperature and the condensing temperature. When this temperature differential becomes very high it is an indication that the compressor is being starved of refrigerant gas. Common reasons for this could be a lack of refrigerant (under-charged or loss-of-charge) or a problem with the expansion device (for example a stuck accumulator or loose wiring to an EEV).

The protection is activated when R32 discharge superheat exceeds 60K for longer than 30 minutes.

The display shows the message 'Hi-dSH' when protection is active.

Hi-dSH

#### 6 Low discharge superheat protection

Discharge superheat is defined as the difference between the compressor discharge gas temperature and the condensing temperature. When this temperature differential stays very low it can be an indication that the compressor is being flooded with liquid refrigerant. Common reasons for this could be an excess of refrigerant (over-charged) or a problem with the expansion device (for example a stuck accumulator or loose wiring to an EEV).

The protection is activated when discharge superheat remains below the threshold for longer than 15 minutes. The threshold varies linearly from 0K at standard mode minimum capacity (40%) to 10K at nominal capacity (100%).

This protection function is disabled when a compressor operates at less than standard mode minimum capacity (< 40%).

The threshold for a variable speed compressor operated in boost mode (capacity above 100%) is fixed at 10K.

The display shows the message 'LO-dSH' when protection is active.

LO-dSH

#### 7 High evaporation temperature / high suction line temperature protection

When the unit has a low pressure transducer connected to the compressor suction line then the controller calculates the evaporating temperature from the suction line pressure reading. If the unit does not have a low pressure transducer then the controller finds the evaporating temperature via a coil temperature sensor (input IC when the unit is cooling, input OC when the unit is heating, yellow wires). Additionally the controller monitors the compressor suction line temperature via a sensor connected to input 'SL' (white wires).

The protection function stops the compressor when:

- The evaporating temperature remains above 27.5°C for longer than 15 minutes.
- The suction line temperature remains above 30°C for longer than 15 minutes.

The display shows the message 'Hi-SL' when protection is active.

Hi-SL

## 8 Other alarms

An external BMS Controller may perform other protection functions. For example:

- Signals from sensors and transducers must remain inside normal operating range.
- Modbus RTU communications with *Carel Power+* inverter must continue uninterrupted.
- Modbus RTU communications with a controller such as a BMS that is controlling the unit must continue uninterrupted.

Refer to document 'UC8 Troubleshooting Guide' for details.

## 9 Lock-out

Each protection function has a trip counter. A trip counter is reset to 0 whenever the compressor run request is removed. Any trip that has occurred more than 12 hours ago is removed from the trip count. For some protection functions, when the trip counter reaches value 3 (i.e. three consecutive trips occur) then the unit is "locked out".

When a unit is locked out the compressor is not allowed to start. Lock-out is designed to protect the compressor from repeatedly starting when a serious fault exists that requires the attention of a service technician.

The display shows the code of the fault that caused the lock-out condition.

A unit that is locked out can be unlocked using any one of the following methods:

- Press the SW3 push button if not using Modbus BMS.
- Remove mains power from the unit for at least 3 seconds, then restore power.
- Issue an 'unlock' command via Modbus RTU serial communications.
- Reset the controller via Modbus RTU serial communications.

## 10 Safety timers

Each UC8 slave controller receives control signals and transfers the signals to the outputs after enforcing safety timers and other protection functions. If the compressor is held off, or held on, by a safety timer then the display shows message 'H-O-L-d'.

Normal durations of safety timers are:













- Minimum off time 3 minutes
- Minimum run time 1.5 minutes
- Min. cycle time 6 minutes (up to 10 compressor starts per hour)
- Min. mode change-over time 10 minutes (cooling to heating or vice-versa)

### Note:

*If a unit operates on low capacity for extended periods then the unit may periodically perform oil flush cycles. Under such operating conditions compressor lubricating oil may slowly settle in parts of the refrigeration system other than the compressor; oil flush cycles help to return the lubricating oil to the compressor. During an oil flush cycle compressor capacity is increased to a certain minimum. The duration of an oil flush cycle is 1 minute.*



**Table 1,** Information available on the UC8 display.

Item	Unit	Abbreviation	Examples
Compressor suction line pressure	kPa	SLP	 Suction line pressure 1034 kPa
Evaporating temperature	°C	Et	 Evaporating temperature 12°C
Compressor suction line temperature	°C	SLt	 Suction line temperature 18°C
Compressor suction side superheat	K	SSH	 Suction side superheat 6K
Compressor discharge line pressure	kPa	dLP	 Discharge line pressure 2447 kPa
Condensing temperature	°C	Ct	 Condensing temperature 42 °C
Compressor discharge line temperature	°C	dLt	 Discharge line temperature 70°C
Compressor discharge side superheat	K	dSH	 Discharge side superheat 28K
De-ice sensor temperature (located on fins of the outdoor coil)	°C	ICEt	 De-ice sensor temperature 39°C
Capacity	%	CAP	 Capacity 100%
Expansion valve 1 opening	%	EE1	 Expansion valve 1 75% open
Expansion valve 2 opening	%	EE2	 Expansion valve 2 75% open

## APPENDIX III


### AIR HANDLING PERFORMANCE

**Note:** Airflows are for a dry coil. Refer Airflow Selection below.


As filters thickness varies, the fan air flows given are for units installed without filters.

Amp figures are 'per phase'.

#### OPA 171



#### OPA 211



#### NB Air Flow Selection

If air returning to the indoor coil is regularly expected to be above 50% relative humidity then the coil face velocity should be limited to 2.5m/s or less (refer air flow graph above)

Consideration must be given to selecting a airflow and coil face velocity that avoids water carry-over problems, ie in high humidity (tropical/subtropical) conditions or when heavily moisture laden fresh air is introduced.

A unit running below or above allowable air flow range can damage components and cause unnecessary unit protection 'tripping'.

## APPENDIX IV

### CONNECTION WIRING PATHS

**IMPORTANT!**  
Don't run low and high voltage wiring in parallel; separate where possible.

BMS comm's wire, up to Ø25 (option).

400V 3 phase power supply wiring conduit, from mains via isolation switch, up to Ø50.

#### NOTE:

Provide weatherproof protection to the connection entry ports as required, such as: cable gland, flexible conduit.

DO NOT install wiring in contact with refrigeration piping unless it is insulated.

Secure external power and BMS comm's cables to prevent wire tension on the terminals.

#### ALTERNATIVE BOTTOM ENTRY HOLES

400V 3 phase power supply wiring conduit, from mains via isolation switch, up to Ø50.

BMS comm's wire, up to Ø25 (option).

DO NOT secure to refrigeration piping unless it is insulated.

# COMMISSIONING CHECK LIST

Site Name/address: .....

Installing Company ..... Date: .....

Serviceman: ..... Tel: .....

Model ..... Serial No. .... Site Ref. ....

Unit mounted level?	Y / N	Supply voltage checked?	Y / N
Temperzone recommended drain trap fitted?	Y / N	External electrical isolator fitted?	Y / N
Water drains tested okay? (panels on, fan running)	Y / N	Indoor EC fan set voltage or l/s	V l/s
Does unit have adequate safe access?	Y / N	Are temperature controller's parameters set?	Y / N
All electrical terminals are tight?	Y / N	Checked for excessive noise & vibration of unit?	Y / N
Return air filters fitted in external ductwork?	Y / N	Has client had controls demo?	Y / N
Removed compressor shipping wedges?	Y / N	Electrical Certificate Of Compliance issued?	Y / N
Refrigeration leak checked?	Y / N	If installed indoors, is there adequate ventilation to disperse any refrigerant in the unlikely event of a leak.	Y / N
Is air flow set and balanced?	Y / N		
Thermostat type:	BMS / TZX-100 / Other? (name):		

## Mark UC8 dip switch positions with an 'X'

	SW1									SW2							
	1	2	3	4	5	6	7	8		9 (1)	10 (2)	11 (3)	12 (4)	13 (5)	14 (6)	15 (7)	16 (8)
On									On								
Off									Off								

## Record the following UC8 monitored conditions using push button SW3 (repeat to scroll through list).

**IMPORTANT:** Digital compressors must be operating at 100% for at least 10 minutes when taking these readings.

		System 1	System 2		
COOLING CYCLE	Low Pressure:	SLP	kPa	Outdoor Ambient temperature:	°C
	Evap temperature:	Et	°C	Indoor Return air temperature:	°C
	Suction Line temperature:	SLt	°C	Indoor Supply air temperature:	°C
	Suction Superheat:	SSH	K	Indoor fan amps :	A
	Discharge Line Pressure:	dLP	kPa	Fresh Air introduced :	%
	Condensing temperature:	Ct	°C	Compressor 1 amps :	A
	Discharge Line temperature:	dLt	°C	Compressor 2 amps :	A
	Discharge Superheat:	dSH	K	Compressor 3 amps :	A
	De-ice Sensor temperature:	ICEt	°C	Compressor 4 amps :	A
	Required Capacity:	CAP	%		
	Expansion Valve 1:	EE1	%		
	Expansion Valve 2:	EE2	%		

HEATING CYCLE	Low Pressure:	SLP	kPa	Outdoor Ambient temperature:	°C
	Evaporating temperature:	Et	°C	Indoor Return air temperature:	°C
	Suction Line temperature:	SLt	°C	Indoor Supply air temperature:	°C
	Suction Superheat:	SSH	K	Indoor fan amps :	A
	Discharge Line Pressure:	dLP	kPa	Fresh Air introduced :	%
	Condensing temperature:	Ct	°C	Compressor 1 amps :	A
	Discharge Line temperature:	dLt	°C	Compressor 2 amps :	A
	Discharge Superheat:	dSH	K	Compressor 3 amps :	A
	De-ice Sensor temperature:	ICEt	°C	Compressor 4 amps :	A
	Required Capacity:	CAP	%		
	Expansion Valve 1:	EE1	%		
	Expansion Valve 2:	EE2	%		

NOTE: This document to be kept with the unit. Failure to provide this completed page on request by Temperzone may affect unit warranty.

[www.temperzone.com](http://www.temperzone.com)

## Auckland

### Head Office

38 Tidal Rd, Mangere, Auckland  
Private Bag 93303, Otahuhu  
New Zealand

**Phone:** (09) 279 5250

**Email:** [sales@temperzone.co.nz](mailto:sales@temperzone.co.nz)

## Sydney

### Head Office

14 Carnegie Place, Blacktown  
NSW 2148  
PO Box 8064, Seven Hills West  
NSW 2147, Australia

**Phone:** (02) 8822 5700

**Email:** [sales@temperzone.com.au](mailto:sales@temperzone.com.au)

## Newcastle

**Phone:** (02) 4692 1155

**Email:** [sales@mcintoshair.com.au](mailto:sales@mcintoshair.com.au)

## Launceston

**Phone:** (03) 6331 4209

**Email:** [info@hvac-supplies.net](mailto:info@hvac-supplies.net)

## Hamilton

**Phone:** (07) 839 2705

**Email:** [tzhamilton@temperzone.com](mailto:tzhamilton@temperzone.com)

## Adelaide

**Phone:** (08) 8115 - 2111

**Email:** [sasales@temperzone.com.au](mailto:sasales@temperzone.com.au)

## Singapore

**Phone:** +65 6733 4292

**Email:** [sales@temperzone.com.sg](mailto:sales@temperzone.com.sg)

## Wellington

**Phone:** (04) 569 3262

**Email:** [wgtn@temperzone.com](mailto:wgtn@temperzone.com)

## Melbourne

**Phone:** (03) 8769 7600

**Email:** [vicsales@temperzone.com.au](mailto:vicsales@temperzone.com.au)

## Christchurch

**Phone:** (03) 379 3216

**Email:** [chch@temperzone.com](mailto:chch@temperzone.com)

## Brisbane

**Phone:** (07) 3308 8333

**Email:** [qldsales@temperzone.com.au](mailto:qldsales@temperzone.com.au)

## Perth

**Phone:** (08) 6399 5900

**Email:** [reception@airskill.com.au](mailto:reception@airskill.com.au)



Materials and specifications are subject to change without notice due to the manufacturer's ongoing research and development programme.