

Copper Pipe

M1 INSULATION



COPPER PIPE (Paired, M1 fire rated insulation) :

053-000-004	6 (1/4") + 10 (3/8") x 20m
053-000-005	6 (1/4") + 13 (1/2") x 20m
053-000-006	6 (1/4") + 16 (5/8") x 20m
053-000-007	10 (3/8") + 16 (5/8") x 20m
053-000-008	10 (3/8") + 19 (3/4") x 20m

LOKRING – Solder-free Tube Connectors

VULKAN

LOKRING



Tooling

460-000-001	LOKbox MZ-V MB 0835 for 6/8/9.5/13/16/19/22/28/35mm dia. pipe
460-000-010	LOKtool MB 25 EVP Assembly Jaws (2 req'd) for 25mm dia. pipe

LOKprep Solution

460-000-020	HT 15 ML (use in ambients from 25°C)
460-000-021	HT 50 ML " " " " "
460-000-022	LT 15 ML (use in ambients up to 30°C)
460-000-023	LT 50 ML " " " " "
460-000-024	Abrasive mat 3 pack

Straight Brass Connectors



460-000-030	6.35 (1/4") NK Ms 50
460-000-031	9.53 (3/8") NK Ms 50
460-000-032	12.7 (1/2") NK Ms 50
460-000-033	16 (5/8") NK Ms 50
460-000-034	19 (3/4") NK Ms 50
460-000-035	22 (7/8") NK Ms 50
460-000-037	28 (1 1/8") NK Ms 50
460-000-038	35 (1 3/8") NK Ms 50

Reducer Brass Connectors



460-000-064	8.00 / 6.35 NR Ms 50
460-000-040	9.53 / 6.35 NR Ms 50
460-000-065	9.50 / 8.00 NR Ms 50
460-000-041	12.7 / 6.35 NR Ms 50
460-000-042	12.7 / 9.53 NR Ms 50
460-000-043	16 / 6.35 NR Ms 50
460-000-044	16 / 9.53 NR Ms 50
460-000-045	16 / 12.7 NR Ms 50
460-000-046	19 / 9.53 NR Ms 50
460-000-047	19 / 12.7 NR Ms 50
460-000-048	19 / 16 NR Ms 50
460-000-050	22 / 12.7 NR Ms 50
460-000-051	22 / 16 NR Ms 50
460-000-052	22 / 19 NR Ms 50
460-000-060	28.6 / 16 NR Ms 50
460-000-061	28.6 / 19 NR Ms 50
460-000-062	28.6 / 22 NR Ms 50
460-000-067	35 / 28.6 NR Ms 50

LOKRING – Solder-free Tube Connectors (cont'd)

VULKAN LOKRING



Stabilisation Inserts

460-000-070	6.35 (1/4") - for 0.8 mm walled tube *
460-000-089	8.00 (5/16") - for 0.8 mm wall tube
460-000-073	9.53 (3/8") - for 0.8 mm wall tube *
460-000-076	12.7 (1/2") - for 0.8 mm wall tube
460-000-077	12.7 (1/2") - for 0.9 mm wall tube *
460-000-079	16 (5/8") - for 0.8 mm wall tube *
460-000-080	16 (5/8") - for 1.0 mm wall tube
460-000-081	19 (3/4") - for 1.0 mm wall tube *
460-000-084	19 (3/4") - for 1.1 mm wall tube
460-000-087	22 (7/8") - for 1.1 mm wall tube
460-000-085	22 (7/8") - for 1.4 mm wall tube
460-000-086	28 (1 1/8") - for 1.2 mm wall tube
460-000-090	35 (1 3/8") - for 1.5 mm wall tube

* Use with temperzone Copper Pipe (page 14).

Note: To ensure a leak free joint it is important to use a Lokring stabilisation insert designed to match the wall thickness of your copper tube.



Elbow Brass Connectors (While Stocks Last)

460-000-094	12.7 (1/2") NBK Cu 50
460-000-095	16 (5/8") NBK Cu 50
460-000-096	19 (3/4") NBK Cu 50
460-000-097	22 (7/8") NBK Cu 50
460-000-098	28 (1 1/8") NBK Cu 50



Elbow Copper Connectors*

460-000-100	9.35 (3/8") Cu 90° EB
460-000-101	12.7 (1/2") Cu 90° EB
460-000-102	16 (5/8") Cu 90° EB
460-000-103	19 (3/4") Cu 90° EB
460-000-104	22 (7/8") Cu 90° EB
460-000-105	28 (1 1/8") Cu 90° EB
460-000-106	35 (1 3/8") Cu 90° EB

* Complete with inserts but need Straight Brass Connectors for each end (see p.1)



Branch Connectors

460-000-203	YP Branch 6.35 (1/4")
460-000-204	YP Branch 9.53 (3/8")
460-000-205	YP Branch 12.7 (1/2")
460-000-206	YP Branch 16 (5/8")
460-000-207	YP Branch 19 (3/4")
460-000-208	YP Branch 22 (7/8")
460-000-209	YP Branch 28.6 (1 1/8")
460-000-211	YT Branch 9.53 (3/8")
460-000-212	YT Branch 12.7 (1/2")
460-000-210	YT Branch 35 (1 3/8")

WARRANTY: 12 months on tools.